


DQ Series Advanced System Amplifiers Quick Reference Sheet

The DQ Series amplifiers offer a wealth of programming functionality, and this quick reference sheet is intended to get the user quick access to the most common functions without the need to consult the user manual. As such, this guide concentrates on core features on the **input** side of the DSP - which gives access to the functions you will need in the vast majority of scenarios.

Accessing the Input Functions

Pressing the **INPUT** key accesses the input functions, and each button press cycles through the four DSP modules in the order of Input A -> Input B -> Input C -> Input D -> Home Screen -> Input A -> Input B etc.




The graphic to the left illustrates this system - so to access the parameters for DSP Module C for example, simply press the **INPUT** key three times.


Navigating the Input Functions

Once in the parameter menu for a given DSP module, you navigate through the parameters by using the **UP** and **DOWN** arrow keys. Detailed overleaf is the full input menu navigation matrix, but the most commonly needed functions are detailed below.

Note: Examples are detailed for accessing the function in DSP Module A, but to reach other modules simply press the **INPUT** key more times as illustrated above.

Gain  Pressing the **INPUT** key once will access the Gain, Polarity and Mute functions for a given DSP module (1 press for A, 2 presses for B and so on).

Recall Preset  To access the Preset Recall function, press the **INPUT** key once, followed by the **DOWN** arrow once.

Input Matrix  To access the Input Matrix press the **INPUT** key once, followed by the **DOWN** arrow three times.

Delay  To access the Input Delay function, press the **INPUT** key once followed by the **UP** arrow once.


Handy Shortcuts

Locking the front panel - press and hold the **UTILITY** key for 10 seconds. Repeat the process to unlock.


Clearing Overlay EQ - Overlay EQ stored on an amplifier by the System Engineer software (illustrated by the amber "overlay" LED on the front panel) can be cleared by pressing and holding the **UTILITY** and **ENTER** keys for 5 seconds.

Back to Home - pressing the **UTILITY** key at any time will return the device to the Home screen.

Full Input Menu Navigation Matrix




KEY



DQ Series Advanced System Amplifiers

Utility Menu Navigation Matrix



KEY

MENU PAGE

MENU BUTTON

Up / Down Button Press
 Menu Button Press